



# ET-LAA110 Projector Panasonic PT-AR100U Lamp For PT-AH1000E PT-AR100EA

#### **Basic Information**

Place of Origin: CHINA
Brand Name: NSHA
Model Number: ET-LAA110
Minimum Order Quantity: 1-1000
Price: Negotiable
Packaging Details: carton packing
Delivery Time: 1-2 day

• Payment Terms: T/T, Western Union, Paypal

• Supply Ability: 5000 per



## **Product Specification**

Product Name: Projector Lamp

Power: 280 WVoltage: 220 V

• Lamp Life: 3000-4994 Hours

• Warranty Period: 240 DAYS

• Lamp Type: OEM OBH OB CBH CB

• Highlight: ET-LAA110 Panasonic Projector Bulb,

Projector PT-AR100U Lamp,

Panasonic PT-AR100U Lamp Replacement



### More Images



## ET-LAA110 For Panasonic Projector Lamp PT-AR100U PT-AH1000E PT-AR100EA

#### **Product Parameter**

Part Numbers	ET-LAA110
Fittable projector	For Panasonic Projector Lamp PT-AR100U PT-AH1000E PT-AR100EA PT-AH1000EA PT-
models	LZ370
Bulb Type	280 W
Life time	3000 -5000(Hours)
Packing	Carton box with foam
Minimum Order	10 piece
quantity	l piece

#### **Product Information**

The Panasonic ET-LAA110 replacement lamps are compatiable with PT-AR100U,PT-AH1000E, PT-AR100EA projectors. The working hour time is:3000-5000 hours, After repalcing our new lamps, the projector performance can be the same of the new original one and improve the effect of projection, and make you feel comfortable while using.

#### **Throw Distance and Screen Size**

The throw distance refers to the distance between the projector and the screen, and it determines the size of the projected image. Different projectors have different throw distances and are suitable for varying room sizes and setups.

#### **Precautions**

Allow Lamp to Cool: Projector lamps generate heat during operation. It is crucial to allow the lamp to cool down completely before attempting to replace it. This prevents the risk of burns or damage to the new lamp.

Use Proper Tools: Prepare the necessary tools for the installation, such as a screwdriver or lamp removal tool, as specified in the user manual. Using the correct tools will ensure a secure and safe installation.

Access the Lamp Compartment: Locate the lamp compartment on your projector. The exact location may vary depending on the projector model. Usually, it is accessible from the top or bottom of the projector or through a side panel. Remove any screws or latches that secure the compartment.

Remove the Old Lamp: Carefully detach the old lamp by following the instructions provided in the user manual. In some cases, the lamp may be held in place by screws or clips. Gently release the lamp and disconnect any cables or connectors attached to it.





## **Guangzhou Crystal Light Electronic Products Co., Ltd.**

18565159850

ancy@projectorlamp-replacement.com

projectorlamp-replacement.com

Guangzhou, China