



55184 SIRIUS HRI 231W Suitable for stage projector lamp 55184 SIRIUS HRI 231W

Basic Information

Place of Origin: CHINABrand Name: VIP

Model Number: 55184 SIRIUS HRI 231W

Minimum Order Quantity: 1-1000
Price: Negotiable
Packaging Details: carton packing

• Delivery Time: 1-2 day

• Payment Terms: T/T, Western Union, Paypal

• Supply Ability: 5000 per



Product Specification

Product Name: Projector Lamp

Power: 231 WVoltage: 220 V

• Lamp Life: 3000-5000 Hours

• Warranty Period: 240 DAYS

• Lamp Type: OEM OBH OB CBH CB

• Highlight: 231w projector bulb replacement,

231w projector lamp replacement, stage projector bulb replacement



More Images



55184 SIRIUS HRI 231W Suitable for stage projector lamp 55184 SIRIUS HRI 231W

Product Parameter

Part Numbers	55184 SIRIUS HRI 231W
Fittable projector models	Suitable for stage projector lamp 55184 SIRIUS HRI 231W
Bulb Type	231 W
Life time	3000-5000(Hours)
Packing	Carton box with foam
Minimum Order quantity	10 piece

Product Information

The Stage lights 55184 SIRIUS HRI 231W replacement lamps are compatiable with 55184 SIRIUS HRI 231W projectors. The working hour time is:3000-5000 hours, After repalcing our new lamps, the projector performance can be the same of the new original one and improve the effect of projection, and make you feel comfortable while using.

Interactive Capabilities

Many projectors come with interactive features that allow users to interact directly with the projected content. This is particularly useful in educational settings, where teachers can annotate, highlight, or manipulate content in real-time during lessons or presentations.

Bulb warranty

Allow Lamp to Cool: Projector lamps generate heat during operation. It is crucial to allow the lamp to cool down completely before attempting to replace it. This prevents the risk of burns or damage to the new lamp.

Use Proper Tools: Prepare the necessary tools for the installation, such as a screwdriver or lamp removal tool, as specified in the user manual. Using the correct tools will ensure a secure and safe installation.

Access the Lamp Compartment: Locate the lamp compartment on your projector. The exact location may vary depending on the projector model. Usually, it is accessible from the top or bottom of the projector or through a side panel. Remove any screws or latches that secure the compartment.

Remove the Old Lamp: Carefully detach the old lamp by following the instructions provided in the user manual. In some cases, the lamp may be held in place by screws or clips. Gently release the lamp and disconnect any cables or connectors attached to it.





Guangzhou Crystal Light Electronic Products Co., Ltd.



18565159850



ancy@projectorlamp-replacement.com



projectorlamp-replacement.com

Guangzhou, China