



OSRAM 54402 SIRIUS HRI 5R Projector Lamp Replacement For Stage

Our Product Introduction

for more products please visit us on projectorlamp-replacement.com

Basic Information

- Place of Origin: CHINA
- Brand Name: VIP
- Model Number: 54402
- Minimum Order Quantity: 1-1000
- Price: Negotiable
- Packaging Details: carton packing
- Delivery Time: 1-2 day
- Payment Terms: T/T, Western Union, Paypal
- Supply Ability: 5000 per



Product Specification

- Product Name: Projector Lamp
- Power: 190 W
- Voltage: 220 V
- Lamp Life: 3000-5000 Hours
- Warranty Period: 240 DAYS
- Lamp Type: OEM OBH OB CBH CB
- Highlight: 54402 OSRAM Projector Lamp,
SIRIUS HRI 5R Projector Lamp,
Stage OSRAM Projector Bulb

Product Description

54402 Suitable for stage projector lamp OSRAM 54402 SIRIUS HRI 5R

Product Parameter

Part Numbers	54402
Fittable projector models	Suitable for stage projector lamp OSRAM 54402 SIRIUS HRI 5R
Bulb Type	190 W
Life time	3000-5000(Hours)
Packing	Carton box with foam
Minimum Order quantity	10 piece

Product Information

The Stage lights 54402 replacement lamps are compatible with OSRAM 54402 SIRIUS HRI 5R projectors. The working hour time is: 3000-5000 hours. After replacing our new lamps, the projector performance can be the same as the new original one and improve the effect of projection, and make you feel comfortable while using.

Scalability

Projectors offer scalability in terms of screen size. Depending on the throw distance and projector specifications, they can project images and videos onto screens of various sizes, accommodating different audience sizes and viewing requirements.

Bulb warranty

Allow Lamp to Cool: Projector lamps generate heat during operation. It is crucial to allow the lamp to cool down completely before attempting to replace it. This prevents the risk of burns or damage to the new lamp.

Use Proper Tools: Prepare the necessary tools for the installation, such as a screwdriver or lamp removal tool, as specified in the user manual. Using the correct tools will ensure a secure and safe installation.

Access the Lamp Compartment: Locate the lamp compartment on your projector. The exact location may vary depending on the projector model. Usually, it is accessible from the top or bottom of the projector or through a side panel. Remove any screws or latches that secure the compartment.

Remove the Old Lamp: Carefully detach the old lamp by following the instructions provided in the user manual. In some cases, the lamp may be held in place by screws or clips. Gently release the lamp and disconnect any cables or connectors attached to it.



Guangzhou Crystal Light Electronic Products Co., Ltd.



18565159850



nancy@projectorlamp-replacement.com



projectorlamp-replacement.com

Guangzhou, China