



RLC-101 Viewsonic Projector Lamp Pro7827Hd Pjd7827Hd Pjd7836Hdl

Basic Information

Place of Origin: CHINA
Brand Name: VIP
Model Number: RLC-101
Minimum Order Quantity: 1-1000
Price: Negotiable
Packaging Details: carton packing
Delivery Time: 1-2 day

• Payment Terms: T/T, Western Union, Paypal

• Supply Ability: 5000 per



Product Specification

• Product Name: Projector Lamp

Power: 240 WVoltage: 220 V

• Lamp Life: 3000-5000 Hours

• Warranty Period: 240 DAYS

• Lamp Type: OEM OBH OB CBH CB

• Highlight: Pjd7827Hd Viewsonic Projector Lamp,

Projector RLC-101 Lamp,

Viewsonic Projector Pro7827Hd Lamp



More Images



Product Description

RLC-101 For Viewsonic Projector Lamp Pro7827Hd Pjd7827Hd Pjd7836Hdl

Product Parameter

Part Numbers	RLC-101
Fittable projector models	For Viewsonic Projector Lamp Pro7827Hd Pjd7827Hd Pjd7836Hdl
Bulb Type	240 W
Life time	3000-5000(Hours)
Packing	Carton box with foam
Minimum Order quantity	10 piece

Product Information

The Viewsonic RLC-101 replacement lamps are compatiable with Pro7827Hd Pjd7827Hd Pjd7836Hdl projectors. The working hour time is:3000-5000 hours, After repalcing our new lamps, the projector performance can be the same of the new original one and improve the effect of projection, and make you feel comfortable while using.

Large Screen Display

One of the significant advantages of projectors is their ability to project images and videos onto large screens or surfaces. This allows for a more immersive viewing experience, making projectors ideal for presentations, home theaters, and public events.

Bulb warranty

Access the Lamp Compartment: Locate the lamp compartment on your projector. The exact location may vary depending on the projector model. Usually, it is accessible from the top or bottom of the projector or through a side panel. Remove any screws or latches that secure the compartment.

Remove the Old Lamp: Carefully detach the old lamp by following the instructions provided in the user manual. In some cases, the lamp may be held in place by screws or clips. Gently release the lamp and disconnect any cables or connectors attached to it.

Install the New Lamp: Take the new lamp and align it correctly with the lamp housing. Make sure it fits securely and matches the connections of the previous lamp. Reconnect any cables or connectors that were disconnected during the removal process.

Secure the Lamp Compartment: Once the new lamp is in place, secure the lamp compartment by reattaching any screws or latches that were removed earlier. Ensure that the compartment is sealed properly to prevent any dust or debris from entering.





Guangzhou Crystal Light Electronic Products Co., Ltd.



18565159850



ancy@projectorlamp-replacement.com



projectorlamp-replacement.com

Guangzhou, China